

INSTALLATION INSTRUCTIONS FORD RANGER MY19 ONWARDS
PART NUMBER: P12-1



INSTALLATION INSTRUCTIONS FORD RANGER MY19 ONWARDS
PART NUMBER: **P12-1**

KIT CONTENTS

- 1 X DOWN STRUT
- 1 X CABLE GUIDE RUBBERS



GUIDE RUBBERS

DOWN STRUT

INSTALLATION INSTRUCTIONS FORD RANGER MY19 ONWARDS PART NUMBER: P12-1



Fitting to slow down strut

1: On the **DRIVERS SIDE** Remove the bolt nearest to the body

2: Place the bracket as shown and replace the bolt and tighten



3: Remove the bolt that holds the cable

4: Replace with the pre assembled strut, making sure the cable is replaced first

INSTALLATION INSTRUCTIONS FORD RANGER MY19 ONWARDS
PART NUMBER: P12-1



6: Install the cable locating rubber on the tailgate as pictured

HSP Ute Lids

40 Overseas Drive, Noble Park Nth, VIC 3174

Phone: 1300 441 498

www.hsputelids.com