

Urbane II Basin Pop-up Waste Assembly Installation Instructions

Plug and Waste Installation Procedure

1. Disassemble the Rubber Washer, Waste Nut and Wing Nut as shown in **Fig. 1**.
2. Apply flexible sealant to the underside face of the Waste Body as shown.
3. Fit Waste Body and Stud into basin waste hole and centralise the Top Cap.
4. Fit Rubber Washer to the Waste Nut and slide onto the Stud and centralise with the underside of the basin waste, secure with Wing Nut and Metal Washer as detailed in **Fig.1. Important: Do not overtighten.**
5. Disassemble the Top Cap from the Pop-up Waste Mechanism as shown in **Fig.1**. The Top Cap assembly can be unscrewed by hand.
6. Wipe away excessive sealant around the flange of the Waste Body.
7. Screw the Top Cap assembly back onto the Pop-up Waste Mechanism. Ensure the Pop-up assembly is centralised with the basin waste.

