



# 'Burton' Outdoor Range

*Boasting the timeless beauty and charm of resin wicker and the durability of an aluminium frame, the 'Burton' outdoor range is ideal for any outdoor space - featuring tempered glass tabletops and stackable dining chairs with removable cushions.*

## CONSTRUCTION

- **Frame:** Aluminium
- **Finish:** Resin Wicker
- **Fabric Material:** Polyester
- **Seat Cushion Filling:** Foam and Fibre
- **Back Cushion Filling:** Polyester

## FEATURES AND BENEFITS

- Stackable dining chairs
- Removable dining chair cushions
- Durable aluminium frame
- Tempered glass tabletop
- Ideal for smaller spaces

## AVAILABLE OPTIONS



**3-Piece Chat Setting**  
(18BUR03.W)

Setting consists of a 69cm round dining table and two cushioned dining chairs.



**5-Piece Round Dining Setting**  
(18BUR05.W)

Setting consists of a 90cm round dining table and four cushioned dining chairs.



**7-Piece Rectangular Dining Setting**  
(18BUR07.W)

Setting consists of a 165 x 90cm rectangular dining table and six cushioned dining chairs.



**4-Piece Lounge Setting**  
(18BURCL.W)

Setting consists of a 2-seater sofa, two armchairs and a rectangular coffee table.

# Harvey Norman®

Store: .....

Staff Member: .....

Phone Number: .....

Measurements are in cm and are approximate only. While we aim to ensure that the information on this fact sheet is correct at the time of printing, it is sometimes necessary for changes to be made to product specifications. To avoid disappointment, we suggest that you obtain confirmation of product specifications and availability with your Harvey Norman Salesperson before placing your order. Images are for illustrative purposes only. Actual product colours may vary. *Accessories shown are not included.*

## PRODUCT DIMENSIONS



**69cm Round Dining Table**  
W69 x D69 x H73cm



**90cm Round Dining Table**  
W90 x D90 x H74cm



**165cm Rectangular Dining Table**  
W165 x D90 x H74cm



**Dining Chair**  
W62 x D66 x H88cm



**Rectangular Coffee Table**  
W100 x D55 x H41cm



**2-Seater Sofa**  
W160 x D78 x H81cm



**Armchair**  
W73 x D78 x H81cm

### CARE INSTRUCTIONS

- Every 4-6 weeks; wash with a mild detergent and warm water, and then rinse with clean water. Ensure it is dried thoroughly to avoid oxidation.
- Dust your furniture regularly as dust may cause the surface to pit.
- Refer to the manufacturer's instruction manual for specific cleaning instructions.

#### Glass

- Dust frequently with a soft cloth.
- Use napery and coasters to protect from scratches.
- Clean with appropriate glass cleaner.

#### Fabric

- Vacuum regularly, clean up spills immediately by blotting; do not rub spillage.
- Store cushions in a dry area when not in use to prolong the fabric's life span.
- Do not machine wash or tumble dry; fabrics may fade when exposed to long periods of sunlight.



# Harvey Norman®

harveynorman.com.au or call 1300 464 278 for your local store.

Measurements are in cm and are approximate only. While we aim to ensure that the information on this fact sheet is correct at the time of printing, it is sometimes necessary for changes to be made to product specifications. To avoid disappointment, we suggest that you obtain confirmation of product specifications and availability with your Harvey Norman Salesperson before placing your order. Images are for illustrative purposes only. Actual product colours may vary.