



‘Marquise’ Outdoor Range

The stunning ‘Marquise’ is perfect for alfresco entertaining all year round. Generously sized and built to last, this range combines a chic granite inlay for serving hot dishes and durable Karri Gum timber for a contrasting on-trend look.

CONSTRUCTION

- **Frame:** Timber - Karri Gum
- **Finish:** Natural
- **Fabric Material:** Polyester
- **Seat Cushion Filling:** Foam
- **Back Cushion Filling:** Foam

FEATURES AND BENEFITS

- Karri Gum table with granite inlay
- Granite inlays act as a hot serving area
- Contemporary square mid-back chairs which include structured black coloured cushions to match the granite inlay.

AVAILABLE OPTIONS



9-Piece Rectangular Dining Setting
(79211)

Setting consists of a 240 x 120cm rectangular dining table and eight cushioned dining chairs.



4-Piece Lounge Setting
(79215)

Setting consists of a 3-seater sofa, two armchairs and a rectangular coffee table.

Harvey Norman®

Store:

Staff Member:

Phone Number:

Measurements are in cm and are approximate only. While we aim to ensure that the information on this fact sheet is correct at the time of printing, it is sometimes necessary for changes to be made to product specifications. To avoid disappointment, we suggest that you obtain confirmation of product specifications and availability with your Harvey Norman Salesperson before placing your order. Images are for illustrative purposes only. Actual product colours may vary. *Accessories shown are not included.*

PRODUCT DIMENSIONS



240cm Rectangular Dining Table
W240 x D120 x H72cm



Dining Chair
W61.5 x D66.5 x H86.5cm



Rectangular Coffee Table
W120 x D60 x H40cm



3-Seater Sofa
W205.5 x D90.1 x H88cm



Armchair
W76.5 x D90.1 x H88cm

CARE INSTRUCTIONS

- Dust your furniture regularly as dust may cause the surface to pit.
- Every 4-6 weeks; wash with a mild detergent and warm water, and then rinse with clean water. Ensure it is dried thoroughly to avoid oxidation.
- Refer to the manufacturer's warranty card for specific cleaning instructions.

Fabric

- Vacuum regularly, clean up spills immediately by blotting; do not rub spillage.
- Store cushions in a dry area when not in use to prolong the fabric's life span.
- Do not machine wash or tumble dry; fabrics may fade when exposed to long periods of sunlight.

Timber

- Ensure all bolts are tightened periodically, as the harsh Australian climate will cause timber to expand and contract, loosening the bolts.
- Keep outdoor furniture covered.
- Dust your furniture regularly as dust may cause the surface to pit.
- Refer to the manufacturer's warranty card for specific cleaning instructions.



Harvey Norman®

harveynorman.com.au or call 1300 464 278 for your local store.

Measurements are in cm and are approximate only. While we aim to ensure that the information on this fact sheet is correct at the time of printing, it is sometimes necessary for changes to be made to product specifications. To avoid disappointment, we suggest that you obtain confirmation of product specifications and availability with your Harvey Norman Salesperson before placing your order. Images are for illustrative purposes only. Actual product colours may vary.