



ROPE DETAIL

‘Masaya’ Outdoor Range

Revitalise your space with the fresh ‘Masaya’ range. Fusing contemporary olive green fabric with hand-woven rope detailing and Eucalyptus timber framing, its deep seating offers the perfect place to sit back and relax.

CONSTRUCTION

- **Frame:** Timber – Eucalyptus, Aluminium
- **Finish:** Rope
- **Fabric Material:** Polyester
- **Seat Cushion Filling:** Foam and fibre
- **Back Cushion Filling:** Polyester

FEATURES AND BENEFITS

- Eucalyptus timber frames
- Hand-woven rope detailing
- Comfortable seating
- Includes cover

AVAILABLE OPTIONS



4-Piece Lounge Setting (K4L-88043)

Setting consists of a 3-seater sofa, two armchairs and a rectangular coffee table.



9-Piece Rectangular Dining Setting (K9D-88041)

Setting consists of a 220 x 90cm rectangular dining table and eight cushioned dining chairs.



7-Piece Rectangular Dining Setting (K7D-88042)

Setting consists of a 180 x 90cm rectangular dining table and six cushioned dining chairs.



5-Piece Rectangular Bar Setting (K5B-88045)

Setting consists of a 160 x 85cm rectangular bar table and four cushioned bar chairs.

Harvey Norman®

Store:

Staff Member:

Phone Number:

Measurements are in cm and are approximate only. While we aim to ensure that the information on this fact sheet is correct at the time of printing, it is sometimes necessary for changes to be made to product specifications. To avoid disappointment, we suggest that you obtain confirmation of product specifications and availability with your Harvey Norman Salesperson before placing your order. Images are for illustrative purposes only. Actual product colours may vary. *Accessories shown are not included.*

PRODUCT DIMENSIONS



3-Seater Sofa
W207 x D84.5 x H75.8cm



Armchair
W79 x D84.5 x H75.8cm



Rectangular Coffee Table
W125 x D65 x H38cm



220cm Rectangular Dining Table
W220 x D90 x H75cm



180cm Rectangular Dining Table
W180 x D90 x H75cm



Dining Chair
W68 x D64 x H82.6cm



160cm Rectangular Bar Table
W160 x D85 x H93cm



Bar Chair
W57 x D50 x H94.6cm

CARE INSTRUCTIONS

- Every 4-6 weeks; wash with a mild detergent and warm water, and then rinse with clean water. Ensure it is dried thoroughly to avoid oxidation.
- Dust your furniture regularly as dust may cause the surface to pit.
- Refer to the manufacturer's warranty card for specific cleaning instructions.

Fabric

- Vacuum regularly, clean up spills immediately by blotting; do not rub spillage.
- Store cushions in a dry area when not in use to prolong the fabric's life span.
- Do not machine wash or tumble dry; fabrics may fade when exposed to long periods of sunlight.

Timber

- Ensure all bolts are tightened periodically, as the harsh Australian climate will cause timber to expand and contract loosening the bolts.
- Keep outdoor furniture covered.
- Dust your furniture regularly as dust may cause the surface to pit.
- Refer to the manufacturer's warranty card for specific cleaning instructions.



Harvey Norman®

harveynorman.com.au or call 1300 464 278 for your local store.

Measurements are in cm and are approximate only. While we aim to ensure that the information on this fact sheet is correct at the time of printing, it is sometimes necessary for changes to be made to product specifications. To avoid disappointment, we suggest that you obtain confirmation of product specifications and availability with your Harvey Norman Salesperson before placing your order. Images are for illustrative purposes only. Actual product colours may vary.