



'Sorrento' Outdoor Range

Perfect for the balcony or a tight outdoor space, the 'Sorrento' setting will bring new life to an otherwise unused space. Convenient space saving design allows for simple storage, while the glass tabletop provides ample space for an outdoor meal.

CONSTRUCTION

- **Frame:** Aluminium
- **Finish:** Resin Wicker
- **Fabric Material:** Olefin
- **Seat Cushion Filling:** Foam
- **Back Cushion Filling:** Foam

FEATURES AND BENEFITS

- For storage space saving, chairs can be tucked flush underneath table
- Hand-woven resin wicker
- Durable aluminium frame
- Available in three sizes to suit spaces from balconies to large patios
- Painted tempered glass tabletop

AVAILABLE OPTIONS



9-Piece Square Dining Setting
(VHO-SORR-01C)

Setting consists of a 124cm square dining table, four cushioned dining chairs and four cushioned foot stools.



5-Piece Rectangular Dining Setting
(VHO-SORR-02C)

Setting consists of a 124 x 65cm rectangular dining table, two cushioned dining chairs and two cushioned foot stools.



11-Piece Rectangular Dining Setting
(VHO-SORR-03C)

Setting consists of a 190 x 124cm rectangular dining table, six cushioned dining chairs and four cushioned foot stools.

Harvey Norman®

Store:

Staff Member:

Phone Number:

Measurements are in cm and are approximate only. While we aim to ensure that the information on this fact sheet is correct at the time of printing, it is sometimes necessary for changes to be made to product specifications. To avoid disappointment, we suggest that you obtain confirmation of product specifications and availability with your Harvey Norman Salesperson before placing your order. Images are for illustrative purposes only. Actual product colours may vary. *Accessories shown are not included.*

PRODUCT DIMENSIONS



124cm Square Dining Table
W124 x D124 x H72cm



190cm Rectangular Dining Table
W190 x D124 x H72cm



124cm Rectangular Dining Table
W124 x D65 x H72cm



Dining Chair
W58 x D58 x H91cm



Foot Stool
W45 x D45 x H33cm

CARE INSTRUCTIONS

- Every 4-6 weeks; wash with a mild detergent and warm water, and then rinse with clean water. Ensure it is dried thoroughly to avoid oxidisation.
- Dust your furniture regularly as dust may cause the surface to pit.
- Refer to the manufacturer's warranty card for specific cleaning instructions.

Glass

- Dust frequently with a soft cloth.
- Use napery and coasters to protect from scratches.
- Clean with appropriate glass cleaner.

Fabric

- Vacuum regularly, clean up spills immediately by blotting; do not rub spillage.
- Store cushions in a dry area when not in use to prolong the fabric's life span.
- Do not machine wash or tumble dry; fabrics may fade when exposed to long periods of sunlight.



Harvey Norman®

harveynorman.com.au or call 1300 464 278 for your local store.

Measurements are in cm and are approximate only. While we aim to ensure that the information on this fact sheet is correct at the time of printing, it is sometimes necessary for changes to be made to product specifications. To avoid disappointment, we suggest that you obtain confirmation of product specifications and availability with your Harvey Norman Salesperson before placing your order. Images are for illustrative purposes only. Actual product colours may vary.