

Anti-Theft Tablet Desk Stand

360° Rotation, Swivel & Tilt



Black

**Black &
White**



For more information: [barkanmounts.com](https://www.barkanmounts.com)

If you are satisfied with the product, please give us a 5 stars ★★★★★ rating on the website you bought it from. If you are not satisfied please contact us at <https://www.barkanmounts.com/support> and we will solve the problem for you.

Tablet Size

7"-14"

17.7cm-35.5cm





Tablet Weight

US	Max	EU
3.1lbs		1.4kg



0-15


**Safety instructions and installation warnings (provided separately)
must be read in full, prior to assembly.**

A Clamp  x1	B Stand  x1	C Key  x2
Z1 Screw  x4	Z2 Allen head bolt  x1	Z3 Washer  x1
Z4 Allen key  x1	Z5 Anti-slip sticker  x4	Z6 PVC pads  x2


Required Tools




No. 2+3



- 1** Place the PVC adaptors inside the clamp holders





- 2** Loosen the screw, open the ruler on the back according to your device size and tighten the screw.
Example – for a device that is 10" to 11", open the ruler to 10".





- 3** Follow the steps according to your preferred method of securing the stand.

Mark the holes on the table and drill with 1/8" \ 3mm drill bit




Tighten the screws to secure the mount to the table




Optional

Attach the adhesive stickers to the bottom of the stand to prevent it from sliding.




Optional lock slot




4

Assemble the clamp on to the stand.




5 Locking


Unlock the clamp



Open the clamp, relock it and take out the key




Close the clamp on your device



6 Tilt adjustment

1. Remove the plastic cover.
2. Using the Allen key (Z6) Tighten the screw in order to create the necessary friction for the tool-free tilt mechanism.
3. Position the tablet at the desired tilt angle.
4. Return the plastic cover.
5. Rotate the tablet to the desired position.



360 ROTATION



TOUCH
& TILT